

SALTER

Electronic Kitchen Scales


Instructions and Guarantee

BATTERIES




3xAAA (supplied)
Ensure +/- terminals are
the correct way round

TO SWITCH ON



- 1) Place bowl on scale before switching on.
- 2) Press and release button.
88888/8 appears on display.
- 3) Wait until display shows **0**.

TO CONVERT WEIGHT UNITS



The default unit of measure is grams (g) to change to imperial measures (lb.oz) press **g-oz** at any time during weighing.
To use the Aquatronic™ liquid measure function press **ml-fl.oz** to change between millilitres (ml) or fluid ounces (fl.oz).

The Aquatronic™ liquid measure feature is suitable for all water based liquids, including wine, milk, stock, cream etc.


Note: Oils have a lower specific gravity, which will result in a volume reading of approx +10%. If measuring oils by volume on this scale, please adjust for this accordingly.

SOLIDS: g = grammes, oz = ounces, lb = pounds

LIQUIDS: ml = millilitres, fl.oz = fluid ounces


If your recipe shows litre or pint measures: 1 litre = 1000 ml, 1 pint = 20 fl.oz, 1/2 pint = 10 fl.oz, 1/4 pint = 5 fl.oz

TO ADD AND WEIGH




To weigh several different ingredients in one bowl, press to reset the display between each ingredient.

AUTO SWITCH OFF



Auto switch-off occurs if display shows **0** for 1 minute or shows the same weight reading for 3 minutes.

SWITCH OFF



Press and hold button (approx. 3 seconds) until the display is blank.

WARNING SYMBOLS



Replace batteries



Weight Overload

CLEANING AND CARE

- If the scale is not being used for a long period, remove the batteries. Always remove flat batteries immediately.
- **DO NOT** immerse the scale in water or use chemical/abrasive cleaning agents.
- The outer casing of the scale may be wiped clean with a damp cloth and the bowl can be washed by hand or by dishwasher.

WEEE EXPLANATION

This marking indicates that this product should not be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.

GUARANTEE

This product is intended for domestic use only. Salter will repair or replace the product, or any part of this product, (excluding batteries) free of charge if within 15 years of the date of purchase, it can be shown to have failed through defective workmanship or materials. This guarantee covers working parts that affect the function of the scale. It does not cover cosmetic deterioration caused by fair wear and tear or damage caused by accident or misuse. Opening or taking apart the scale or its components will void the guarantee. Claims under guarantee must be supported by proof of purchase and be returned carriage paid to Salter (or local Salter appointed agent if outside the UK). Care should be taken in packing the scale so that it is not damaged while in transit. This undertaking is in addition to a consumer's statutory rights and does not affect those rights in any way. For UK Sales and Service contact HoMedics Group Ltd, PO Box 460, Tonbridge, Kent, TN9 9EW, UK. Helpline Tel No: (01732) 360783. Outside the UK contact your local Salter appointed agent.



SALTER

HoMedics Group Ltd

PO Box 460, Tonbridge, Kent, TN9 9EW, UK.
www.salterhousewares.co.uk

GB